


Ceramic hob

General handling and tips

Ceramic hob



The hotplates have a glass ceramic surface. It is sensitive to impact shocks and can crack as a result.

The cookware used should always have the same base diameter as the selected hotplate. The hotplate may crack during cooling if this requirement is ignored.

Please note when selecting cookware that aluminium pans can leave traces of aluminium on the hotplate at high temperature settings. It may not be possible to remove these discolourations.

Always use a commercially available ceramic hob cleaning agent to clean the hotplates. As with any other glass surface, the use of abrasive cleaning agents is highly inadvisable.

Please see the enclosed operating instructions for additional useful information.