

Extractor hood

General handling and tips

Extractor hood


The active carbon filter in extractor hoods used to recirculate air must be replaced or, in the case of long-life filters, regenerated from time to time depending on the degree of saturation to ensure that the appliance works properly.

Make sure that exhaust air extracted to the outside is replaced by fresh supply air by opening a window.

Metal grease filters can be cleaned in the dishwasher. Use the programme with the highest temperature. Dishwasher detergents can cause the grease filters to take on a slightly tainted, dull-grey appearance over time, but this does not affect functionality.



Metal grease filter



Activated carbon filter

Sales
Customer Service
Replacement Parts

CHE - 105.929.116 MWST

Tel.	0848 801 002	Fax	0848 801 017
Tel.	0848 801 001	Fax	0848 801 003
Tel.	0848 801 005	Fax	0848 801 004

Credit Suisse, 8070 Zurich CH62 0483 5143 6281 8100 0